

ROSTYLE RE-VAMP KIT INTRUCTIONS – W545



CONTENTS:

25 x Masking pads
1 x Real masking tape
3 x Wet and dry sheets
2 x Can silver paint
1 x Can black paint

1. Carefully rub down the rim, taking care to make sure this is done thoroughly. Time taken here will result in a better Finish.
2. Once rubbed down make sure that the rim is clean, dry and grease free. You can now apply the silver paint, taking care to follow the instructions on the side of the can.
3. Now leave the rim for a 24 hr period to allow the paint to fully cure.
4. You can now apply the masks to the wheel centre only, leaving exposed the part of the wheel you wish to black. Make sure that the outside rim is also masked off.
5. To obtain a good key for the black paint, gently rub down those areas before spraying.
6. You can now apply the black paint, again following the instructions on the side of the can.
7. After approximately 1/2hr remove the masking by peeling each section back on itself to reveal the finished result.
8. Now leave for another 24hr period before running the rims on the car. This will make sure that the paint is fully cured and will not streak.