

V740 MG MGZS ZS SAIC 2017 2018 2019 Wind & Rain Deflectors

INSTALLATION ADVICE

1. Thoroughly clean and dry the door tops using hot soapy water.
2. To install start with one visor at a time
3. Remove 2-3 inches of the self-adhesive backer at the front and rear ends of the visors (do not place down on a dusty surface).
4. For the front visors, use a pair of long nose pliers to carefully turn the metal tang at the front lower ends of the visors so they are clear of the door frame when offering up.
5. Engage the rear metal hanger over the metal door lip and between the door seal.
6. Check for door clearances and reposition as necessary being sure to check the hanger is located in the channel properly between door top and seal are in place.
7. Use a blunt plastic object to carefully push the metal tang into the lower part of the wing mirror cheater.
8. Peel away the rest of the self-adhesive backer by pulling gently on the 3 inch tag
9. Firmly pressing down.

Tips: You can use a hairdryer on the door if it is a cold day to warm up the door tops just before you stick the visors on as it will better activate the adhesive. Inadequate or uneven pressure applied to the visor during installation or the ambient temperature being too cold to activate the adhesive will reduce adversely affect adhesion. If jet washing the car try not to use the hi-pressure lance between the visor and the door. Hand washing in these areas being preferred. If you require to remove and refit the visors replacement self-adhesive tape is readily available through eBay, we do not stock separately.