

CLUB ROLLOVER BAR - FITTING INSTRUCTIONS

Before attempting to fit, read the instructions carefully and check the condition and contents of the items supplied.

Contents: 1 - Club Rollover bar with fitted cover.
4 - Backing Plates.
8 - 11/16" Headed Bolts. .
8 - 11/16" Nuts.
8 - Shake-proof Washers.

Fitting Instructions

Place the bar in position in the rear of your MG, ensuring that the foremost hoop is upright as possible whilst still allowing the rear mounting plates to locate properly on the wheel arches.

IMPORTANT NOTE –

Check that the areas of the car to which the mounting plates are to be bolted are in sound condition, and have not been weakened by rust. If corrosion has occurred, reinforcing plates should be welded into place before proceeding further.

The bar mounting plates, should be located over fixed sections of carpet (ie wheel arches), but it is best to trim around detachable carpet sections to allow removal for cleaning.

Mark the centres of the eight mounting holes and drill using a 7/16" drill bit.

Bolt together keeping bolt heads inside the car, and fastening the reinforcing backing plates, shake-proof washers, and nuts from the underside. Coat the underside with Waxoyl or grease to prevent corrosion.

