

Upper Splash Shield Fitting Instructions K180L/R

Kit Contents

MB18S	Upper Splash Shield SS (Left or Right)	X 1
AS23	ACME Scre No 10 ¾"	x 3
BHH209M	Seal	40cm

Note It is advisable to apply liberal rust prevention treatment to the inner wing reinforcement area prior to installing the upper splash shields as this area is inaccessible following fitment.

1. Fit the seal to the top edge of the upper splash shield (see dashed line)
2. Remove the two upper most screws from the splash shield
3. Secure the upper splash shield over the top of the existing splash shield and refit both splash shield screws.
4. Mark and predrill the lower screw hole fixings using a 3mm metal drill bit (noting access is better afforded following removal of the wing)
5. Secure the lower edge of the upper splash shield using the acme screws.

