




MG3 MUDFLAP FITTING INSTRUCTIONS



(Always ensure the vehicle is safely secured and cannot fall when using the wheel jack)

FRONT

The front mudflaps can be fitted without removing the wheel but for ease of fitting it is recommended to remove. Turn Steering Wheel to full (right or left depending on side you are fitting) lock. Offer the mudflap up in position and firstly screw the bottom screw through the support arm into the hole. Firmly push the top of the mudflap into position and either mark the hole positions required or drill through while in position. Place the spire nuts behind the holes drilled and screw through to firmly fix in position, tighten the bottom screw.



REAR

It will be necessary to remove the rear wheel to install the rear mudflaps. Offer the mudflap up and hold firmly into position, either mark the hole positions required or drill through while in position. Secure the top position first to ensure there is no gapping in the corner at the top, then the lower screw and finally tighten.

