

SPRITE & MIDGET WIND DEFLECTOR

FITTING INSTRUCTIONS

Tools required - 7/16th AF socket or spanner

We would suggest you read these instructions first to give you an idea of the sequence of fitting this item.

Fold the hood back into its open condition against the rear cockpit.

Remove the two lower 7/16th bolts that hold the hood frame to the body.

Fit the bracket supplied and insert bolts and tighten.

Fit the washers in sequence as shown here.

Metal washer against wind deflector, fibre washers either side of bracket.

Insert the threaded part of the wheel into either end of the wind deflector and tighten.

That's it - Happy motoring!

