

INTERIOR TRIM PRODUCTS

INSTRUCTIONS FOR USING SPRAYABLE CONTACT ADHESIVE

SAFETY

Before using any sprayable chemical product ensure that the work area is well ventilated, in a confined space it is recommended that the operator should wear an approved respiratory mask and appropriate eye protection as per the instructions on the can.

- When gluing trim materials directly to a metal surface. Ensure that the metal is clean, free from rust, dust or any loose material. Clean off any deposits of previously applied adhesive using a Glue & Tar remover and allow the surface to dry thoroughly.
- Shake the can thoroughly to mix the contents.
- Bear in mind that when using an adhesive spray can, most of what flows through the nozzle is solvent (used to thin down the adhesive enough to make it sprayable) and propellant. So where a strong bond is required we recommend that you first spray the metal area and the back of the trim material where required, so that an even coat of adhesive is visible.
- When the first coat of adhesive is dry (usually after approx 15 minutes) spray both surfaces again. This will ensure that you have sufficient adhesive in place.
- The two surfaces can now be carefully brought together.
- Please be aware that by using this technique you will give the adhesive its maximum performance but that you will need to position the material very carefully before contacting the two surfaces.