

BURR WALNUT DASHBOARD – TYPE 4

FITTING INSTRUCTIONS

Contents of Fitting Kit:

13 x No.4 ½" screws
1 x Twist Drill

IMPORTANT: Before attempting to fit your Walnut Dashboard please inspect all the panels ensuring that they are the correct type for your MG Model. Check the contents of the fitting kit and read the instructions fully. If the carton containing your panels is damaged on delivery, then please notify the Club immediately.

- 1 Prior to fixing any panels and with the assistance of a friend, position the panels on the dashboard to visualise the correct fitment, i.e. overall alignment. Position the boards to ensure that the glove box has sufficient clearance to open and close.
- 2 Holding the glove box door panel in position, mark through the fixing holes with a point, then remove the panel and drill. The panel can then be fixed using the screws with the correct size cross-headed-screwdriver.
- 3 Position the centre rectangular panel relative to the glove box door panel, mark, drill and then fix in position.
- 4 Position the left-hand panel relative to the glove box door panel mark, drill and then fix in position.
- 5 Position the right-hand panel, mark, drill and fix in position.'
- 6 Position the main instrument fascia which will butt against centre and right-hand panels, and ensuring all instrument holes are correctly aligned, mark drill and fix into position.

Before leaving the factory a final quality inspection is carried out on each panel. The panels are then wrapped in tissue paper and boxed in a strong carton that offers maximum protection.

CARE AND PROTECTION

The panels are sealed with a high gloss polymer coating that prevents any penetration of moisture. The panels may be polished with a furniture spray type polish and buffed with a soft cloth. Small or light accidental scratches may be removed by buffing with a wax polish.