

1. Needle
2. Piston Spring
3. Damper Assembly/Cap
4. ○ Jet Assembly
5. ○ Needle and Seat Kit includes item 32
6. ■ Float Kit includes item 32
7. ■ Throttle Spindle Kit includes 12,13, 57 & 60
8. ■ Throttle Disc Kit includes items 12,13 & 60
9. Gasket Pack includes items marked ●
10. Service Kit includes items marked ○
11. Rebuild Kit includes items marked ■
12. ● Gasket - Air Inlet
13. ● Gasket - Engine Flange
14. Thermo Jet Bearing Kit
 - a Copper Washer
 - b Top Bearing
 - c Cork Gland
 - d Washer Gland
 - e Spring
 - f Bottom Bearing
 - g Bottom Bearing Washer
 - h Cork Gland
 - i Sealing Ring
 - j Jet Sealing Nut
 - k Spring
 - l Jet Adjusting Nut
 - m Cork Washer set
15. Idle Adjusting Screw Kit
 - Adjusting Screw
 - Spring
16. Throttle Stop
17. Throttle Lever
 - a Bolt
 - b Nut
 - c Washer
18. ● Damper Cap Washer
19. Suction Chamber Screws
20. Suction Chamber and Piston Assy
21. Needle Lock Screw
22. Lift Pin/Ticker Pin Kit
 - Lift Pin
 - Spring
 - Split Pin
23. Banjo Bolt
24. ● Banjo Washer
25. Banjo Union
26. Filter
27. Float Lid Cap Nut (Long)
28. ● Washer
29. ● Serrated Washer
30. Overflow Pipe (Where Fitted)
31. Float Lid Assembly
32. ● Float Lid Gasket
33. Float Fork
 - Copper
 - Stainless
34. Float Lever Pin
35. Float Chamber
36. Holding Up Bolt
37. ● Fibre Washer
38. ● Steel Washer
39. ● Fibre Washer
40. Holding Up Bolt (Alt. to item 36)
41. Dished Washer
42. ● Rubber Grommet # 1
43. Holding Up Stud
44. Nut
45. Steel Washer
46. Steel Washer
47. ● Fibre Washer
48. Fast Idle Cam Kit
49. Jet Link
50. Jet Return Spring
51. ■ Clevis Pin
52. ■ Split Pin
53. ■ Clevis Pin (Alt. to 51)
54. ■ Starlock Washer (Use with 53)
55. Jet Lever
56. Throttle Return Spring Kit
57. ■ Taper Pin
58. Coupling Assembly
59. Throttle Connecting Rod
60. ■ Disc Screws
61. ■ Spindle Bush
62. Body
63. Float Lid Cap Nut (Short)
64. Overflow Cap

Rubber grommets are only used on certain vehicles and NOT supplied in this kit. If required please ask upon ordering.